

2019 Royal Mail Rate Upgrade

Jet+250

Fitting Instructions

PLEASE ONLY LOAD THE CARD ONCE BEFORE 25TH MARCH 2019, LOADING TWICE WILL DELETE YOUR PREVIOUS TARIFF.

These tariffs can be loaded now. Tariffs will automatically update only on the effective date (please see www.royalmail.com/prices2018 for details).

If you experience any problems after loading your tariff card, please turn your machine off then back on again.

Should you require any assistance please call our Customer Support team on 0118 9519800 or Email support@twofold.co.uk

1	SWITCH THE FRANKING MACHINE ON AND WAIT FOR THE READY MODE
2	PRESS OK AND THE SCROLL (<>) TO MEMORY CARD
3	PRESS OK THE INSERT CARD WITH GOLD CHIP AT THE BOTTOM, FACING TOWARDS YOU
4	PRESS OK TWICE AFTER A SHORT PERIOD MACHINE WILL SAY "MEMORY CARD LOADING COMPLETE"
5	TO RETURN TO WELCOME SCREEN (STANDBY MODE) TURN THE MACHINE OFF AT THE POWER SUPPLY, WAIT FOR 5 SECONDS THEN RESTART MACHINE. THE CARD CAN NOW BE REMOVED.